

OPERATING YOUR EMV

FIRST/SECOND RESPONDERS GUIDE - LOCATION OF MSDS

If the Low and High Voltage Disconnect switches are not accessible, Zone 2 high voltage isolation can be accomplished by disconnecting the two Level 2 MSDs at the front of the vehicle.

Colored areas outlined in image below represent areas of isolation and cable color coding.

